

Firmware Updating Instructions for SeaLife Micro 3.0 Camera

SeaLife released firmware update V1.07 for the Micro 3.0 camera, which improves the following:

- Compatibility updates for Android 12
- Compatibility updates for iOS 15
- Improved microphone recording volume while underwater
- Other minor bug fixes

You may update the firmware using the SeaLife Micro 3+ app or by following the below instructions. Updating the firmware using the app is the fastest, easiest way. Please refer to the [online troubleshooting](#) instructions if you need help updating the firmware using the SeaLife Micro 3+ app.

Firmware Update Procedures

1. Before starting firmware update, make sure camera's battery has at least 50% charge.
2. Download firmware from the following link and save it to your PC desktop:
https://www.dropbox.com/s/4bz049b17it10ya/sealife_fw.bin?dl=0
3. Connect camera to your PC using the USB cable. For Windows PC, the camera will appear as a drive called "MICRO3.0" located in "My Computer". For Mac, the camera USB drive will appear on your desktop.
4. Copy the "sealife_fw.bin" file from your desktop and paste it to the "MICRO3.0" drive. *Note: Make sure the "sealife_fw.bin" file name has not been altered (must be "sealife_fw.bin") and that it is located under the DCIM folder, like this:*

Name	Date modified	Type	Size
DCIM	9/21/2020 5:21 PM	File folder	
MISC	9/21/2020 5:21 PM	File folder	
sealife_fw.bin	9/2/2020 3:13 AM	BIN File	47,504 KB

5. Disconnect the camera from the computer and Power on camera.
6. "Processing..." appears on the display, indicating FW update is in progress. It takes about 30 seconds to update. The FW file automatically deletes after the update has successfully been installed in the camera.
7. To confirm that the firmware has updated correctly, power on the camera, push the Menu key, select "System Settings" using the up/down keys and push shutter button to confirm. Scroll up one step to "Firmware Version:" which should show V1.07. That's it. Happy Diving!